



# Getting Started

## The BlackBerry Handheld



- 1 **Power Key** – Press to turn the handheld on or off.
- 2 **Home Screen** – Displays frequently used applications and information, such as date, time, and battery level.
- 3 **Convenience Key** – Press to open the assigned application. *(By default, the Convenience key opens Voice Dialing.)*
- NEW!** 4 **Trackball** – Roll to move the cursor and click to select an item or to enter a selection. *(In an open application, click the trackball to display the short menu.)*
- 5 **Send Key** – Press to display the Call Log and place a call.
- 6 **Menu Key** – Press to display available applications from the Home screen or to display the application menu from an open application.
- 7 **Alt Key** – Press to enter the alternate character on a key.
- 8 **Left Shift Key** – Press to capitalize characters. *(To turn on Num Lock, press Alt + Left Shift.)*
- 9 **Space Key** – Press to insert a space. Press twice to insert a period.
- 10 **Mute Key** – Press to turn the microphone on or off during a call.
- 11 **Volume Keys** – Press to adjust the volume during a call.
- 12 **Escape Key** – Press to exit a menu, dialog box, or screen.
- 13 **End Key** – Press to end a phone call or return to the Home screen from any other screen.
- 14 **Backspace/Delete Key** – Press to delete characters.
- 15 **Enter Key** – Press to enter selections.
- 16 **Speakerphone Key** – Press to turn speakerphone on or off during a call or to insert a currency symbol.
- 17 **Right Shift Key** – Press to capitalize characters. *(To turn on Cap Lock, press Alt + Right Shift.)*
- 18 **Symbol Key** – Press to open the symbol list and insert a symbol.

*Note: Some symbols and icons may vary depending on the 8800 series model and the service provider. Changing the theme will also affect the icons.*

## Included Applications

The following applications are included with BlackBerry software. If the **Applications** screen is not displayed, press the **Menu** key, or roll the trackball to select **Applications** and click the trackball.

- Setup Wizard** – set up options to personalize your device.
- Messages** – manage e-mail, PIN, SMS, and MMS messages.
- Call Log** – view recent calls and place phone calls.
- BlackBerry Messenger** – communicate with other BlackBerry users in real time using this instant messaging program.
- Calendar** – keep track of your schedule.
- Address Book** – store and add contact information.
- Browser** – browse Web pages and set bookmarks for frequently visited sites. *(The Web browser and its icon may vary depending on your service provider.)*
- Media** – store and view pictures, ring tones, videos, and songs. **NEW!**
- Profiles** – customize how you are notified of messages, phone calls, and events.
- Tasks** – create, edit, and manage tasks.
- MemoPad** – compose, edit, and delete memos.
- Alarm** – set the alarm on your handheld.
- Voice Dialing** – dial phone numbers using voice commands.
- BrickBreaker** – destroy bricks with this default game.
- Calculator** – perform mathematical calculations.
- Password Keeper** – store passwords and private information.
- Help** – get help for using BlackBerry applications.
- Search** – search for items from a central global search.
- Maps** – get directions and find businesses, restaurants, and other services using interactive maps. **NEW!**
- Options** – change options, such as date, time, screen and keyboard options, security options, and theme.
- Manage Connections** – turn off the wireless radio when it can interfere with other radio communications.
- Keyboard Lock** – prevent accidentally typed characters and unauthorized use.
- Turn Power Off** – turn off the handheld when you do not want to receive messages or to conserve battery.

*Note: To switch applications, press and hold the Alt key and press the Escape key. Roll the trackball to select the application and release the Alt key.*

## Selecting Items and Entering Selections

- To select an item, roll the trackball to move the cursor and click the trackball or press the **Enter** key to select the item.
- To select multiple items, press the **Shift** key and roll the trackball.
- To change an option in an options field or to check or clear a check box, press the **Space** key.
- To view all available options in an options field, select the field and press the **Alt** key.

*Note: You can now scroll horizontally using the trackball.*

**NEW!**