



Getting Started


The iPhone



- 1 **Ring/Silent Switch** – Slide to switch between ring and silent mode.
- 2 **Volume Buttons** – Press the adjust ringer volume.
- 3 **Touchscreen** – Use to navigate your iPhone.
- 4 **Home button** – Press to return to your Home screen.
- 5 **Sleep/Wake button** – Press to lock or press and hold to turn on or off.
- 6 **Status Bar** – displays status icons, including cell signal, Wi-Fi, and battery.
- 7 **Application Icons** – Press to open an application.

Working with Applications

1. Press and hold an application icon. *(The icons will start wiggling.)*
2. Do any of the following:
 - To move an application icon, press and drag the icon to the desired location. *(You can move application icons between screens.)*
 - To delete an application, press the **Delete** (X) button in the upper-left corner of the application icon. Press the **Delete** button to confirm deletion.
3. Press the **Home** button when you are finished.



Note: You cannot delete default applications.

Changing the Screen Orientation

To switch between portrait and landscape view, rotate your iPhone to the right or left.

Note: This is not available in all applications.

Using Default Applications

The following applications are included by default on your iPhone. Some features and services may not be available in all areas.

- Phone** – make calls and access Voicemail.
- Mail** – manage e-mail using your existing e-mail accounts.
- Safari** – browse Web pages and set bookmarks.
- iPod** – listen to music and watch movies.
- Text** – send and receive SMS text messages.
- Calendar** – keep track of your schedule.
- Photos** – store and view photos.
- Camera** – take digital photographs.
- YouTube** – play videos from YouTube’s Web site.
- Stocks** – view automatically updated stock information.
- Maps** – displays maps, finds your current location, gives driving directions and traffic conditions.
- Weather** – displays current weather and a six-day forecast.
- Voice Memos** – record, edit, manage, and share audio memos.
- Clock** – set the time, alarm, stopwatch, or timer.
- Calculator** – make calculations.
- Notes** – create, store, and send notes.
- Settings** – change iPhone settings, such as sounds, wallpaper, and phone settings.
- iTunes** – store, play, or download music.
- App Store** – browse and download applications.
- Compass** – displays the geographical coordinates of your current location and displays which direction you are facing.

Installing an Application

You will need a valid iTunes account to install an application.

1. Press the **App Store** (A) icon.
2. Do one of the following:
 - To view featured applications, press **Featured**.
 - To view applications in specific categories, press **Categories**. Press the category you want to browse.
 - To view the **Top 25 applications**, press **Top 25**. Press **Top Paid** or **Top Free**.
 - To search for an application, enter a word or phrase in the **Search** box and press the **Search** button.
3. Select the application you want to install.
4. Press the button that displays the price of the application.
5. Press the **Install** or **Buy Now** button.
6. If prompted, enter your iTunes password and press the **OK** button.

Note: You can also install applications using iTunes on your computer.